



www.alba.es

CANOPY BRANDS EUROPE, S.L.U.

Polígono Ind. Bayas c/ Suzana Parc.134

09200 MIRANDA de EBRO (Burgos)

☎ (+34) 947 347 820


✉ : comercial@alba.es ; 🌐 : www.alba.es

MAST CLIMBING WORK PLATFORM

PEC 90

USER GUIDE

- INSTALLATION, USE & MAINTENANCE INSTRUCTIONS
- SPARE PARTS LIST



ENGLISH

COPY

Machine No.:

Year of manufacture:

Electric connection:

KEEP THIS GUIDE FOR FUTURE REFERENCE

CONTENTS

1. DESCRIPTION OF THE MACHINE	3
1.1 Introduction	3
1.2 General information	4
1.3 Technical data	5
1.4 Main components.....	6
1.5 Main dimensions and weights	9
1.6 Safety devices of platform	14
2. ASSEMBLY OF THE MACHINE.....	15
2.1 Introduction.....	15
2.2 Transport and handle.....	15
2.3 Machine erection procedure	16
Step 1 Base to ground positioning.....	16
Step 2 Base levelling and resting on floor.....	19
Step 3 Assembly of platform	20
Step 4 Assembly of handrails, door and ladder	24
Step 5 Assembly of floor extensions and inner side perimeter protection	25
Step 6 Electrical equipment connection.....	28
Step 7 Adjusting levelling system	29
Step 8 Assembly of mast column.....	30
Step 9 Assembly of mast anchorage.....	31
Step 10 Assembly of end track cams and red mast	35
Step 11 Assembly of mast protector	36
Step 12 Filling MCWP handover certificate	36
2.4 Dismantling platform	37
3. USING THE MACHINE	49
3.1 Introduction	49
3.2 Use of control panel	40
3.3 Emergency stop	41
3.4 Emergency lowering	41
3.5 Checking platform operation before commissioning.....	43
3.6 Setting OUT OF SERVICE	43
3.7 Environmental conditions for safe use of machine	44
3.8 Intended applications	45
3.9 Applications and uses forbidden	45
3.10 Annex for PEC-90M single-phase with 230V supply.	46
4. MAINTENANCE OF THE MACHINE	47
4.1 DAILY Maintenance.....	47
4.2 PERIODICALLY Maintenance	58
4.3 Instructions for troubleshooting.....	59
4.4 Maintenance record	60
4.5 Breakdown record	62
ANNEX I: Load diagram.	
ANNEX II: Handover certificate (Template)	
TEST CERTIFICATE	
EC DECLARATION OF CONFORMITY	
ELECTRICAL SCHEME	
LIST OF ELECTRICAL COMPONENTS	
SPARE PARTS LIST	

The user's manual must be kept in good condition. This document contains 64 pages.
Canopy brands Europe S.L.U. reserves the right of incorporating contents or modifications at any time with the purpose of improving both the machine and the information available on the same.



Copyright © Canopy brands Europe S.L.U.
Rev. 04: Jan. 2025

1. DESCRIPTION OF THE MACHINE

1.1. Introduction.

Prior to erection and use, all users must read this manual. A thorough reading is recommended for full compliance with safety regulations.

This manual is delivered with the hoist, and its purpose is to give instructions for proper handling during transportation, erection and maintenance, in compliance with the provisions of EU Directive 2006/42/CE on safe machinery. This instruction manual deals with proper use of the machine as well as proper erection and maintenance.

The manufacturer reserves the right to modify the machine for improvements, so that differences may be found in some manual details. In any case, the manufacturer commits to immediately adapt the manual to the improvements.

Responsibility:

CANOPY BRANDS EUROPE, S.L.U., declines any responsibility for damage caused by improper use of the machine as consequence of non-compliance with the provisions of the present Manual. Specifically declines any responsibility for damages derived from:

- Non-compliance with the provisions of this manual.
- Improper use of the machine.
- The use of non-original spare parts mentioned in the applicable section of this manual.
- Modifications introduced without express authorisation from the manufacturer.
- Handling by personnel not trained for this purpose.

Only appointed trained personnel may use the machine and only qualified technical personnel acquainted with the machine may operate on any part of the same.

This manual must be available to the user at any time for any type of immediate consultation. In order to maintain it in perfect conditions, keeping always a copy close to the machine is recommended.

In any case, the manual is aimed at knowledge strengthening and as a reminder for the personnel, who must previously be well trained by engineers or supervisors, who at the same time must be very experienced in this machine operation.

1.2. General information.

The rack and pinion mast climbing work platform is based on the principle of geared motor transmission to a rack and pinion mechanism. Components are modular and easy to install. It is simple to use and safe for facade work or rehabilitation, significantly reducing the erection time and man-hours.

This machine has been designed for temporary installation on site to work over facades and vertical structures, in single or double mast version depending on total work length. Its main advantage is the ability to access to work point for materials and persons in a fast and safe way. Below, please find the main points to bear in mind prior to erection and use of the machine.

- The platform is designed for transporting **persons, along with their equipment and materials.**
- The machine runs vertically, geared to the mast rack and guided with support rollers.
- Machine operation must be carried out by **personnel appointed** by the person responsible for the machine on site. Operators must be trained in safe use of platform.
- For erection, dismantling, maintenance and repair tasks, only **competent technical personnel** are allowed. These personnel must work under the overseeing and directing of a person qualified, and with practical experience. They must be trained in:
 - Understanding of assembly plan, dismantling or transformation of the platform.
 - Safety rules on assembly, dismantling or transformation of the platform.
 - Measures to prevent falling of persons or material.
 - Security measures in case of changing weather conditions that could adversely affect the safety of the work platform.
 - The permissible load conditions, and other risks arising from those operations.
- Responsible for installation will prepare an ASSEMBLY PLAN for the platform, which will contain the manufacturer's general instructions contained in this manual. Assembly plan will be completed with **MCWP HANDOVER CERTIFICATE** (See example in Annex III), including specific features and capabilities of the installation. Any information on special assemblies not contained in the general instructions of manufacturer is to be added as ANNEX into assembly plan.
- The machine is designed to be fixed to intervals adapted to a structure, i.e. concrete structure of construction building, a metallic structure, or similar. ALBA includes in the user's manual of the machine all the necessary information relative to loads transmitted to the structure of vertical support and to the ground. It is a responsibility of the responsible of contractor technical personnel to assure that, both the structure of support and the ground, support the loads indicated by the manufacturer.

1.3. Technical data.

TECHNICAL FEATURES:

	SINGLE MAST	TWIN MAST
Maximum length:	6,81 m.	22,62 m.
Maximum load:	1.000 Kg.	2.100 Kg.
Vertical speed:	7 m/min.(50 Hz) 8,5 m/min.(60 Hz)	
Platform width:	800 mm	
Platform extension:	· Standard: 600 mm · Max: 1.000 mm ^(*)	
Motor power:	2 x 0,75 KW.(50 Hz) 2 x 0,90 KW.(60 Hz)	4 x 0,75 KW.(50 Hz) 4 x 0,90 KW.(60 Hz)
Maximum height:	90 m ^(**)	
Anchorage each (max.):	6 m.	
Height over last anchorage:	1,5 m.	
First anchorage height (max.):	6 m.	
Loading height-to-ground:	900 mm.	
Reference normative:	2006/42/CE, EN-1495	
Mast	Square tube	
Length:	1,5 m.	
Weight:	39 Kg	

(*) Case of longer floor extension, ask manufacturer.

(**) Case of higher installation, ask to manufacturer.

ELECTRIC FEATURES:


	SINGLE MAST		TWIN MAST	
	50 Hz	50 Hz	50 Hz	60 Hz
Motor power:	2 x 0,75 KW.	2 x 0,75 KW.	4 x 2,2 KW	4 x 2,65 KW
Input power connection:	400 V – 50Hz	400 V – 50Hz	400 V – 50Hz	460 V – 60Hz ^(*)
Power consumption:	1,5 KW	1,5 KW	8,8 KW	10,6 KW
Nominal current:	4 A.		8 A.	
Supply power:	5 KVA		10 KVA.	
Starting current:	20 A.		40 A.	
Overload protection ^(**)	4 x 16 A.			
Differential protection ^(**)				
Calibre:	16 A.			
Sensitivity:	300 mA.			
Control voltage:	48 V.			
Aux. hand tools socket:	230 V – 50Hz 16 A 265 V – 60Hz 16 A			
Cable section:	5 x 2,5 mm ²		5 x 4 mm ²	

(*) Transformer 220-460V available for 220V-60Hz main supply. Ask the manufacturer.


Optional: Available single-phase connection 230V-1ph-50/60Hz. Single mast: 10 A / Twin mast: 20 A.

(**) Required on electric main supply point where machine is connected.

1.4. Main components





SINGLE MAST PLATFORM




TWIN MAST PLATFORM

- **MAST BASE SUPPORT:**
Main structure that is used as a support for the hoist and for the column of masts. It transmits the efforts generated to the ground. It has rotating stabilizers for levelling and support jacks. Base also incorporates buffers to avoid the platform hitting metallic structure.
- **MAST:**
Modular structure for the vertical movement of the machine. It consists of a modular square tube of 1,5 m. It has one welded rack for the travel of platform across. Mast modules are designed for their union by means of screws and for the anchorage to a vertical structure of support to suitable intervals.
- **MOTOR GROUP:**
Structure that incorporates gearmotor system and that provides the movement to the platform. It incorporates both the gearmotor and the safety systems to control the movements of the machine. It fits to the platform by means of bolts on the sides of the chassis.
- **PLATAFORM:**
Modular horizontal working structure, with several length possibilities, which are fitted ones to each other by means of 3 safety bolts with pins and chains to avoid losing the pins. Platform modules are made by a tubular structure in a triangle truss, with a metallic floor at the top area serving as a working zone. It has handrail brackets and it's possible to assemble modular extensions of the main platform.
- **EXTREME SIDE HANDRAILS:**
Lateral handrails on the platform sides to cover the whole perimeter of the platform. They have brackets to fit them to the platform with superior bolts, and also to extend protection to auxiliary extension floor if necessary.
- **ANCHORAGE:**
That's the system of mast anchorage to an external support structure. There is several anchorage arm's length, depending on distance to façade when installing the platform.
- **CONTROL SWITCHBOARD:**
It contains the main electrical components of the platform, and the control knobs, and it's connected to the electrical supply with a feed cable (not supplied with the platform). The cable is collected into the cable bin (supplied with the platform)
- **CABLE BIN:**
It's used to wind the electrical supply wire when the platform moves, avoiding cable hitch. The cable bin receives wire winding inside.
- **FINAL MAST MODULE:**
Mast module without rack that is installed in the top limit of the column of masts. It prevents that the machine exceeds the top limit of the mast, and its red colour allows immediate identification.


1.5. Main dimensions and weights




SINGLE MAST PLATFORM




TWIN MAST PLATFORM




BASIC MACHINE SET (SHIPPING)




PLATFORM SET



-  **7 Kg**
-  **4 Kg**
-  **2,5 Kg**




PLATFORM EXTENSION
± 730




-  **20 Kg**


ANCHORING SETS




39 Kg



MAST SET



15 Kg



CONTROL BOARD SET

1.6. Safety devices of platform

- a) Geared motors with **electromagnetic brakes** (friction type) capable to brake at speeds of 7 m. /min. (and even 25% overspeed) with a deceleration of 0.1 up to 0.2 g. with maximum load.
- b) Rubber buffers to damp eventual frame impacts against the base.
- c) Limit switches at first mast and next to last mast. Stop the platform when reaching the lower or upper limit switches.
- d) Upper and lower safety limit switch. Operate in case of failure of upper or lower limit switches.
- e) Rear frame extension detection switches. Stop the platform when going passed an anchor in case the extensions between the mast and the facade have not been removed.
- f) Inductive mast presence detector to be used mainly during mast erection.
- g) **Automatic platform levelling** instrument. Prevents the platform from being tilted during up or down travel. Redundancy to prevent failures. In case the redundant instrument operates, the platform gets blocked.
- h) Manual **Emergency down travel** in case of power outage, with speed control through centrifugal brake
- i) Railing with skirting board on the entire platform and skirting board on facade side.
- j) Non-slip steel platform deck.
- k) Platform access ladder. Easy and safe access to Platform.
- l) Mast protector. Prevents eventual trapping when the hoist is in motion.
- m) End mast (in red), without rack, to prevent the cage from running off in case of failure of other systems.

NOISE EMISSION DECLARATION

	Condition
	Control panel position
A-weighted emission sound pressure level, L_{pAd}:	70 dB
Values determined according to the acoustic test given in EN 12159 with use of basic international standards EN ISO 3744 y EN ISO 4871.	
Note: Noise emission values "declared combined" are the sum of the measured values and uncertainty. Represent an upper limit of the range in which the measured values are susceptible to be present.	

2. ASSEMBLY OF THE MACHINE

2.1. Introduction.

The following section is dedicated to the safely assembly of the machine. The installation of the hoist can only be performed by TECHNICAL PERSONNEL, who have received adequate training.

**WARNING:**

FOR INSTALLATION OF PLATFORM SHALL BE USED PROTECTIVE EQUIPMENT AGAINST FALLS FROM HEIGHT (ACCORDING TO EN 358, EN 361, EN 364) AND IN ANY CASE A PROTECTIVE HELMET FOR THE HEAD (ACCORDING TO EN 397), PLUS ADDITIONAL MEANS OF PROTECTION.



It is important to follow the instructions described in detail, so that to avoid risks in the process of Assembly and disassembly of the machine. The user is obliged to observe, for if itself, and by all those who work in the vicinity, all sources of additional risk, as well as to comply with all security standards required for the type of equipment used.

2.2. Transport and handle.

The work platform is supplied unassembled, in accordance with the sets that are specified in the Apdo.1.5. Also indicates the dimensions and weights of the main assemblies to be handled during installation.

**IMPORTANT:**

FOR ASSEMBLY OF THE COMPONENTS AND PLATFORM MOUNTING, IT IS RECOMMENDED TO USE A BUILT-IN CRANE TRUCK, OR IF AVAILABLE, THE CRANE TOWER OF THE WORK IS GOING TO BE USED.



IF IT'S NOT AVAILABLE, 3 PERSONS ARE REQUIRED TO HANDLE COMPONENTS.

2.3. Machine erection procedure:



IMPORTANT:

BEFORE STARTING PLATFORM ASSEMBLY, IS IMPORTANT TO PLAN THE PLATFORM POSITION AT THE BUILDING SITE, WITH SPECIAL ATTENTION TO:

- **LENGTH AND EXPECTED PLATFORM CONFIGURATION.**
- **INTENDED USE FOR THE PLATFORM.**
- **MIN. DISTANCE TO FACADE - 20 cm.**
- **INSTALLATION OF AUXILIARY EXTENSIONS.**
- **Nº OF ANCHORS AND DISTANCE BETWEEN ANCHOR POINTS.**
- **INTENDED LENGHT OF ANCHOR ARMS.**
- **....**



IMPORTANT:


CHECK THAT THE POSITION CHOSEN FOR THE INSTALLATION ALLOWS ASSEMBLY OF THE PLATFORM WITHOUT APPROACHING ANY DANGEROUS POINT IN ITS VERTICAL TRAJECTORY.

MINIMUM DISTANCE BETWEEN TWO ADJACENT WORK PLATFORM IS 0.5 M TO AVOID RISK TO PLATFORM USERS.



IN CASE OF NEED A SPECIAL CONFIGURATION OF PLATFORM, OR MODIFICATION OF THE STANDARD FEATURES, ASK THE MANUFACTURER TO PROVIDE DRAWINGS WITH SPECIFIC DIMENSIONS AND FEATURES AND ADD IN AS ATTACHMENT TO THE ASSEMBLY PLAN.

- **Step 1. Base to ground positioning**




POSITIONING BASES AT THE GROUND


ATTENTION:

PUT MOTOR GROUPS AT PLANNED INSTALLATION POINTS WITH SPECIAL ATTENTION TO THE POSITION OF THE ELECTRICAL CONNECTOR



- TWIN MAST: PUT MOTOR GROUP SO THAT THE LEVELING MICROS AND CONNECTORS ARE FACING THE INSIDE
(IN CASE THAT THE TWO GROUPS ARE THE SAME, MICROS AND CABLE OUTPUT POSITION SHOULD BE CHANGED IN ONE OF THEM)
- SINGLE MAST: INSTALL EITHER ONE OR ANOTHER GROUP


BASE POSITIONING OPTIONS

ATTENTION:

THE BASE CAN BE MOUNTED WITH THE STABILIZERS IN VARIOUS POSITIONS. IF POSSIBLE, CHOOSE THE POSITION OF THE JACKS MORE SEPARATED.

IF STABILIZERS ARE NOT INSTALLED, FIRST ANCHOR IS TO BE MOUNTED AT 2 M.


ASSEMBLY WITH STABILIZERS

ASSEMBLY WITHOUT STABILIZERS




IMPORTANT:

CHECK THE RESISTANCE OF SOIL TO WITHSTAND MAXIMUM LOADS TRANSMITTED TO GROUND BY THE PLATFORM DURING OPERATION.

IT'S RECOMMENDED TO USE WOOD PLATES OF 40x40 cm. FOR A CORRECT SUPPORT OF THE JACKS.

SPECIAL ATTENTION TO JACKS NEXT TO THE MAST, ON WHICH RESTS THE MAIN WEIGHT OF THE MACHINE, ENSURING THAT TOUCH THE GROUND PROPERLY.



LOADS TO GROUND DISTRIBUTION



IMPORTANT:

MAXIMUM PLATFORM LOADS TRANSMITTED TO GROUND:

	TOTAL LOAD (EST.) [KN]	TOTAL LOAD (DIN.) [KN]
SINGLE MAST	34	39
TWIN MAST	71,5	81,3

(x225) = [lbf]

USE THE ABOVE VALUES TO VERIFY THAT THE GROUND IS CAPABLE OF SUPPORTING THE LOADS TRANSMITTED AT EACH POINT.


CASE OF SPECIAL ASSEMBLIES, CONTACT THE MANUFACTURER.

GROUND RESISTANCE EXAMPLES	
MATERIAL	MAX PRESS.
CRYSTALLINE SOLID ROCK	20.000 Kg/m ²
SEDIMENTARY ROCK	1000 Kg/m ²
STONE OR GRAVEL	1000 Kg/m ²
SAND, MUDDY SAND, MUDDY GRAVEL	700 Kg/m ²
SAND, CLAY, MUD	450 Kg/m ²


ATTENTION:

IF IN DOUBT ABOUT THE CHARACTERISTICS OF SUPPORTING SOIL, IT'S RECOMMENDED TO USE LOAD DISTRIBUTION PLATES. IF INSTALL THE MACHINE ON A HOLLOW FLOOR OR BASEMENT ACCESSIBLE, IT'S NECESSARY TO UNDERPIN BOTTOM IN THE PLATFORM BASE AREA.

- Step 2. Base levelling and resting on floor.


ATTENTION:

LEVEL VERTICALLY PLATFORM BASE, ACTING ON THE LEVELLING JACKS. USE A SPIRIT LEVEL ALONG ON TWO PERPENDICULAR FACES OF FIRST MAST IN THE PLATFORM BASE.


ATTENTION:


ONCE PLATFORM BASE IS LEVELED, SUPPORT FIRMLY THE BASE CENTRAL JACKS. BLOCK STABILIZERS IN ITS POSITION WITH THE PIN, TO AVOID FHURTER MOVEMENT.

• Step 3. Assembly of the platform




ATTENTION:
ONCE THE BASE IS LEVELED AND CENTRAL JACK LEANING ON THE GROUND, YOU CAN START ASSEMBLY OF THE MODULAR PLATFORM.

ASSEMBLY OF PLATFORM: SINGLE MAST




1: INFERIOR BOLT



2: SUPERIOR BOLTS




IMPORTANT:
CASE OF SINGLE MAST PLATFORM, INSTALL CHASSIS BLOCKING BOLT, SO AS TO PREVENT FREE MOVEMENT OF THE BOTTOM CHASSIS ARM.



3: MONTAJE SIMETRICO DE LAS PLATAFORMAS



IMPORTANT:
COMPLETE ASSEMBLING MODULES ON BOTH SIDES OF THE CHASSIS GROUP ALTERNATELY UNTIL DESIRED LENGTH.




ATTENTION:
NEVER EXCEED THE MAXIMUM PLATFORM LENGTH INDICATED ON THE LOADS DIAGRAM.
CASE OF MOUNTING A SINGLE MAST PLATFORM, IT'S NECESSARY AN INITIAL CONFIGURATION WITH A MAXIMUM OF 1 + 1 MODULES AND, ONCE COLUMN OF MASTS AND ANCHORS ARE MOUNTED, COMPLETE ASSEMBLY OF PLATFORM MODULES TO DESIRED LENGTH.
¡NEVER EXCEED MAXIMUM PLATFORM LENGTH 3,81 m. [1,5 m – 0,81 m – 1,5 m], WHEN PERFORMING ASSEMBLY OR DISMANTLING OPERATIONS !




IMPORTANT:
MAXIMUM LENGTH IN SINGLE MAST CONFIGURATION IS 6,81 M. REFER TO THE LOADS DIAGRAM TO SELECT LIMITS OF LOAD DEPENDING ON ASSEMBLY CONFIGURATION CHOSEN.


ASSEMBLY OF PLATFORM: TWIN MAST



IMPORTANT:
CASE OF TWIN MAST PLATFORM, FREE THE LOCK CHASSIS BOLT, ALLOWING THE FREE MOVEMENT OF CHASSIS BOTTOM ARM.



ATTENTION:
USE AN EASEL FOR THE MOUNTING OF MODULES OF CENTRAL PLATFORM, USING IT AS A POINT OF SUPPORT TO ASSEMBLY PLATFORM MODULES. YOU CAN USE A PLATFORM MODULE REVERSED AS AN EASEL.




ATTENTION:
ONCE CENTRAL PLATFORM LENGTH IS COMPLETED, INSTALL RIGHT MOTOR GROUP AND GET IT CLOSE TO THE PLATFORM TO JOIN IT UP TO THE LAST PLATFORM WITH THREE BOLTS. REMOVE THE LOWER CHASSIS GROUP BOLT.


IMPORTANT:

FOR A CORRECT OPERATION OF THE PLATFORM THE RELATIONSHIP OF PLATFORMS BETWEEN THE SIDES AND THE CENTRAL BRIDGE MUST BE OF 1 TO 4. PROVIDE FOR THE CONFIGURATION LIKE SHOWN BELOW:

Nº OF LATERAL PLATFORM MODULES (L1)	Nº OF CENTRAL PLATFORM MODULES (L2)
1 x 820	From 1 to 3
1 x 1500	From 4 to 6
1 x 1500 + 1 x 820	From 6 to 8
2 x 1500	From 9 to 10



FINAL CONFIGURATION OF TWIN MAST PLATFORM


ATTENTION:

COMPLETE ASSEMBLY OF THE REMAINING PLATFORM MODULES ON THE PLATFORM RIGHT SIDE. MAKE SURE THAT TWO BOTTOM BLOCKING CHASSIS BOLTS ARE OUTSIDE OF LOCKED POSITION, ALLOWING THE FREE MOVEMENT OF INFERIOR CHASSIS ARM.


IMPORTANT:

MAXIMUM LENGHT IN TWIN MAST CONFIGURATION IS 22,62 M. REFER TO THE LOADS DIAGRAM TO SELECT LIMITS OF LOAD DEPENDING ON ASSEMBLY CONFIGURATION CHOSEN.


IMPORTANT:

THE CONFIGURATION OF THE PLATFORM SHOULD BE SYMMETRICAL TO AVOID MALFUNCTION OR DAMAGE. IF IT IS NOT POSSIBLE TO INSTALL SYMMETRICAL PLATFORM CONFIGURATION, CONSULT RESTRICTIONS TO MANUFACTURER.


IMPORTANT:


TO FINISH THE ASSEMBLY OF THE WORK PLATFORM, MAKE SURE THAT ALL BOLTS AND THEIR SAFETY PINS ARE PROPERLY INSTALLED.

ALSO MAKE SURE THAT THE BASES ARE VERTICALLY LEVELED AND CENTRAL JACKS REST ON THE FLOOR PERFECTLY


• Step 4. Assembly of handrails, door and ladder




ATTENTION:
INSTALL GUARDRAILS AROUND THE PERIMETER OUTSIDE OF PLATFORM. LOCK INTO POSITION WITH FIXING SCREWS. INSTALL EXTREME HANDRAILS, USING THE NUTS AND BOLTS OF UNION OF PLATFORMS AND ANCHORING WITH A CLAMP TO SIDE HANDRAIL.



INSTALLING HANDRAILS




FASTENING HANDRAILS




EXTREME HANDRAIL




ATTENTION:
MOUNT THE ENTRANCE LADDER AND TIGHTEN FIXING SCREW TO CHASSIS. FINALLY FIT THE DOOR INTO POSITION AND FIX FASTENING SCREWS. COMPLETE ASSEMBLY BY ADJUSTING ACCESS LADDER.



INSTALLING ACCESS DOOR



FASTENING SCREWS



INSTALLING LADDER


- Step 5. Assembly of floor extensions and inner side perimeter protection.



IMPORTANT:

ONCE MOUNTED PROTECTION ON THE EXTERIOR OF THE PLATFORM PERIMETER, PROTECTION MUST BE INSTALLED IN THE INNER AREA.

THE PLATFORM ALLOWS THE INSTALLATION OF AUXILIARY MODULAR FLOOR EXTENSIONS ON THE INNER SIDE.



PERIMETER ENCLOSURE OF THE PLATFORM



IMPORTANT:


INSTALL THE MODULAR FLOORS EXTENSION, AND SUBSEQUENTLY PROTECTION AT THE INNER SIDE OF THE PLATFORM, SO THERE'S NO DANGEROUS GAPS FOR USERS OF THE PLATFORM. INSTALL ADDITIONAL POSTS TO PROTECT THE SIDES OF THE EXTENSION FLOOR.



IMPORTANT:

MODULAR FLOORS MUST BE INSTALLED ADJUSTING FIRMLY IN THE EXTENSION SUPPORTING TUBES, FOLLOW THE STEPS:

- 1. EXTRACT EXTENSIBLE, AT MOST UNTIL THE STOP SCREW.**
- 2. PLACE MODULAR FLOORS VERY TIGHT ONE ON EACH OTHER**
- 3. BLOCK THE MOVEMENT OF EXTENSION TUBES.**
- 4. FIT EXTENSION FLOOR TUBE TO EXTENSION SUPPORT TUBE WITH BRIDLES**



DISTANCE TO FACADE AND INNER PROTECTION

PROTECTION	A	B	C
If $d < 0,25$ m	X		
If $0,25$ m $< d < 0,40$ m	X	X	
If $d > 0,40$ m	X	X	X (*)

(*) Case of $d > 0,40$ m. protections A+B+C can be replaced with a standard handrail


EXTENSION INSTALLING OPTIONS




IMPORTANT:
ALWAYS RESPECT THE INDICATIONS OF THE TABLE TO AVOID THE RISK OF FALLING OF THE WORKERS OR MATERIALS FROM THE PLATFORM.
INSTALL THE PLATFORM TO A DISTANCE MINIMUM OF 20 CM OF FACADE, TO AVOID THE RISK OF HITTING WITH THE STRUCTURE OF BUILDING.




IMPORTANT:
DON'T USE AS AUXILIARY EXTENSIONS FLOOR DIFFERENT OTHER THAN THOSE SUPPLIED BY MANUFACTURER.




**EXTENSION TUBE
STOP AND BLOCKING**




**LATERAL POST SUPPORT
098.4810**




**LATERAL PLINTH SUPPORT
086.405**




FITTING WITH SCREWS




FIXATION PLANK (CLIENT)



MAX. POST DISTANCE



086.488



086.433



086.48



086.43

INNER PROTECTION POST. 3 Kg/un.


IMPORTANT NOTES ABOUT USING EXTENSIONS:

- MODULAR FLOORS ARE AUXILIARY EXTENSION, AND ONLY USE FOR WORK IS ALLOWED FOR PEOPLE AND THEIR EQUIPMENT.
- DURING THE MOVEMENT OF PLATFORM, THE USERS THAT WORK IN THE EXTENSIONS IS TO BE LOCATED IN THE MAIN PLATFORM.
- EXTENSION TUBES OF SPECIAL LENGTHS SHOULD BE USED WITH EXTREMELY CAUTION, DUE TO THE INCREASE IN SIZE OF PLATFORM THAT PRODUCE.
- IN ANY CASE, IT RECALLS THAT AUXILIARY EXTENSIONS AND ALL THEIR ACCESSORIES, SUCH AS HANDRAILS, POSTS... IS COUNTED AS PAYLOAD, AND ITS WEIGHT MUST BE DEDUCTED FROM LOAD CAPACITY OF THE PLATFORM FOR EACH CONFIGURATION. THE NEW LIFTING CAPACITIES MUST BE REGISTER ON THE MCWP HANDOVER CERTIFICATE
- WHEN REQUIRING A CHANGE IN THE CONFIGURATION OF THE PLATFORM, ONCE EXTENSIONS ARE INSTALLED, SUCH MODIFICATION MAY ONLY BE PERFORMED SAFELY BY AUTHORIZED PERSONNEL. THE CHANGE AND THE NEW LOAD CAPACITY MUST BE REPORTED ON THE MCWP HANDOVER CERTIFICATE.
- IN CASE OF DOUBT REGARDING THE USE OF EXTENSIONS AND CORRECTED LOAD CAPACITY, CONSULT THE MANUFACTURER.

• Step 6. Electrical equipment connection.



IMPORTANT:

INSTALL THE CONTROL PANEL ON THE HANDRAIL AT A POINT FROM WHICH YOU HAVE THE BEST VIEW OF THE COMPLETE PLATFORM, PREFERABLY IN CENTRAL ZONE.



IMPORTANT:

CONNECT THE ELEVATOR TO A POWER SOCKET WITH MAGNETOTHERMAL AND DIFFERENTIAL PROTECTION AVAILABLE. THE CONNECTION ONLY BE CARRIED OUT BY QUALIFIED TECHNICIANS.


INSTALLATION ELECTRICAL DATA

	50 Hz	60 Hz
CONNECTION:	400 V	460 V
POWER/EACH GROUP:	2 X 0,75 KW	2 X 0,9 KW
SUPPLY POWER:		
• SINGLE MAST:		5 KVA
• TWIN MAST:		10 KVA
NOMINAL CURRENT:		
• SINGLE MAST:		4 A
• TWIN MAST:		8 A
CROSECTION WIRE		
• SINGLE MAST:		5 X 2.5 mm ²
• TWIN MAST:		5 X 4 mm ²
MAGNETOTHERMAL PROTECTION (*) [3~ / 1~]		16/25 A
DIFFERENTIAL PROTECTION (*) [3~ / 1~]		16/25 A
• SENSIBILITY:		300 mA


(*) Elements required on electric supply board on site.

Connect earth point of the base frame to a proper earth wire on site.

Case of monophase supply: 230V-50Hz. Inom: 10 A. (single mast), Inom: 20 A. (twin mast)



INSTALLING CONTROL BOARD



INSTALLING CABLE HOLDER


IMPORTANT:

CASE OF SINGLE MAST, CONNECT THE GROUP CONNECTOR IN ONE OF THE CONNECTORS OF THE CONTROL PANEL AND ON THE OTHER SIDE THE BRIDGE CONNECTOR. IF THE BRIDGE ISN'T INSTALLED, THE PLATFORM DOES NOT WORK.


IMPORTANT:

INSTALL THE CONTROL PANEL ON THE PLATFORM AT THE POINT INDICATED. IT'S NOT ALLOWED THE MOVEMENT FROM A CONTROL POINT NOT SITUATED ON THE OWN PLATFORM.

- Step 7. Adjusting levelling system.


IMPORTANT:





BEFORE MOVING THE PLATFORM, CHECK THAT ALL THE CABLES ARE WELL GUIDED AND FIXED WITH BRIDLES TO THE STRUCTURE OF THE PLATFORM.


ATTENTION:

CHECK IF THE PLATFORM IS PERFECTLY HORIZONTAL BEFORE INSTALLING THE LEVELING SYSTEM. IF THE PLATFORM IS NOT LEVELED, USE THE BUTTONS OF THE CONTROL PANEL MANUAL FOR LEVELING.

MAXIMUM MISLEVELMENT ON NORMAL OPERATION: 2°

ONCE PLATFORM IS LEVELED MANUALLY, INSTALL AUTOMATIC LEVELING SYSTEMS AT THE POINTS INDICATED IN THE CENTRAL PLATFORM:


INSTALLING CAM (LEFT SIDE)

INSTALLING CAM (RIGHT SIDE)

LEVELLING AND SAFETY SWITCHES


• Step 8. Assembly of mast column.



ATTENTION:
SEE CHAPTER 3. USING THE MACHINE, BEFORE LIFTING THE WORK PLATFORM. MAKE SURE THAT ALL THE PERIMETER PLATFORM RAILINGS ARE INSTALLED CORRECTLY.




ATTENTION:
DUE TO THE MOVEMENT OF THE PLATFORM, MOUNTING OF MAST COLUMN IS A DANGEROUS OPERATION AND SHOULD BE PERFORMED WITH EXTREME CAUTION. FOR THE MAST COLUMN ASSEMBLY 2 PERSONS ARE REQUIRED.



LOADS ON THE PLATFORM DURING MAST COLUMN ASSEMBLY



ATTENTION:
MOUNT ON THE PLATFORM, AS CLOSE TO THE MAST AS POSSIBLE, MAST MODULES, FASTENING SCREWS AND TOOLS REQUIRED.
NEVER EXCEED 50% OF THE CAPACITY OF LOAD DEPENDING ON CONFIGURATION.



MINIMUM CLEARANCE OF MAST

MOUNTING MAST SCREWS


ATTENTION:

WEIGHT OF MAST MODULE IS 39 Kg.

USE SCREWS QTY. 8:8: (TORQUE: 60 N·m)


3 X SCREW M12X90 DIN 931, WASHER A13 DIN 125 AND NUT M12 DIN 985


CAUTION:

FIT / REMOVE MAST AND SCREWS ALWAYS AT THE SAME TIME!

NEVER RAISE THE HOIST OVER A NON-SCREWED MAST MODULE!

THEN THERE IS A HIGH CHANCE OF COLLAPSE AND SERIOUS INJURY!



- Step 9. Assembly of mast anchorage.




IMPORTANT:


ANCHOR THE MAST COLUMN TO THE FACADE OR SUPPORTING STRUCTURE, MAXIMUM EACH 12 m ACCORDING TO LIMITATIONS INDICATED.

INSTALL FIRST ANCHOR AS SOON AS POSSIBLE, FOR EXAMPLE, IN THE FIRST REINFORCED CONCRETE FLOOR OF THE BUILDING.


IF THE BASE IS INSTALLED WITHOUT STABILIZERS, DUE TO THE LIMITATION ON THE STABILITY OF THE BASE, THE FIRST ANCHOR WILL BE PERFORMED AT 2 m.

CASE OF SINGLE MAST, REMEMBER TO LIMIT LENGTH OF PLATFORM ON EACH SIDE OF THE GROUP TO ASSEMBLY MAST COLUMN AND ANCHORS.


1) Mounting anchorage.

INSTALLING ANCHORAGE BRACKET

DIFFERENT BRACKET POSITIONS



1) Fastening to structure.



ATTENTION:
BOTH SIDES OF THE MAST MUST BE VERTICALLY 90° LEVELLED AND ALSO MAST TWISTING, BEFORE CLAMPS ARE FITTED TO THE SUPPORT STRUCTURE.
USE A SPIRIT LEVEL ALONG TWO ADJACENT SIDES OF THE MAST VERTICAL TUBES.

3) Max. forces to the structure

IMPORTANT:

TO TAKE INTO ACCOUNT THE EFFECT OF THE WIND IN SERVICE IN THE CALCULATION OF THE ANCHORS, A FORCE [Fv] IS ADDED TO THE VALUES RX, Ry APPLIED IN MOST UNFAVOURABLE DIRECTION (Y).

DON'T INTRODUCE PROTECTIVE SCREENS OR OTHER ELEMENTS THAT MAY MODIFY THE WIND RESISTANCE OF THE PLATFORM WITHOUT CONSULTING WITH THE MANUFACTURER.

MAX. ANCHORAGE FORCES (examples)


Case of $V_a=V_b=25$	L (mm)	$D_1=D_2$ (mm)	P1 [KN]	P2 [KN]	R1 [KN]	R2 [KN]
	350	200				
	550	325	1,90	-0,73	1,09	0,41
	675	375				

(x225)=[lbf]


ATTENTION:


BE SURE OF THE STRENGTH OF SUPPORT STRUCTURE TO WITHSTAND THE MAXIMUM TRANSMITTED LOADS. IN CASE OF INSTALLING AN ANCHOR IN A DIFFERENT PROVISION, CONSULT THE MANUFACTURER.

4) Recommended anchorage system.



RECOMMENDED: HSA-K M12X120 (or SIMILAR)		
ø _o	Drill diameter	12 mm
h ₁	Minimum drill depth	95 mm
h _{nom}	Minimum mounting depth	80 mm
L	Anchor length	120 mm
T _{ins}	Screw length	300 N·m

5) Interference checkup.





ATTENTION:
CHECK 4 POINTS OF POSSIBLE INTERFERENCE INDICATED, BEFORE FITTING TO THE STRUCTURE. MOVE THE ANCHOR ARMS IF NECESSARY.


ATTENTION:
CONTINUE WITH ASSEMBLY OF MAST COLUMN UNTIL DESIRED HEIGHT, WITH ANCHORS MAXIMUM, EACH 6 m.

FROM 50 m. HEIGHT, ANCHORAGE DISTANCE WILL BE REDUCED ALTERNATING ANCHORS EACH 3/6 m.



• Step 10. Assembly of end track cams and red mast.



UPPER ENDTRACK CAM



LOWER ENDTRACK CAM



ENDTRACK CAMS AND RED MAST



ATTENTION:

INSTALL UPPER AND LOWER ENDTRACK CAMS, AND CHECK IF THE PLATFORM STOPS CORRECTLY WHEN REACHING UPPER OR LOWER LIMIT.


FINALLY, INSTALL THE RED MAST WITHOUT RACK.

• Step 11. Assembly of mast protector.




ATTENTION:

TO COMPLETE PLATFORM ASSEMBLY, MAST PROTECTOR WILL BE INSTALLED IN THE MOTOR GROUP, SO AS TO PREVENT CONTACT OF USERS OF PLATFORM WITH MOTIONLESS PARTS OF MAST.



MAST PROTECTOR



FITTING MAST PROTECTION

• Step 12. Filling MCWP handover certificate



IMPORTANT:

ONCE THE PLATFORM IS INSTALLED, AND BEFORE COMMISIONING TO PERSON RESPONSIBLE ON SITE, FILL THE MCWP HANDOVER CERTIFICATE, WHERE INSTALLATION PARTICULAR CHARACTERISTICS ARE DEFINED.

CONSULT THE LOAD DIAGRAM TO DEFINE THE PAYLOAD CAPACITY DEPENDING ON CONFIGURATION LENGTH CHOSEN. WHEN INSTALLING A SPECIAL CONFIGURATION, CONSULT THE MANUFACTURER.

SEE A MCWP HANDOVER CERTIFICATE EXAMPLE AT THE END OF THE MANUAL.

2.4. Dismantling the platform

For disassembly of the platform will do the reverse described above, with special care on the tasks with risk of people falling from the platform.


Step 1. Dismantling mast and anchors.

Remove first the red mast and then the column of masts and anchorages.




IMPORTANT:

**i MOUNT/DISMANTLE SCREWS AND MAST AT THE SAME TIME!
NEVER RAISE THE PLATFORM OVER A MAST WITHOUT SCREWS
OTHERWISE, THERE IS A HIGH PROBABILITY OF ACCIDENT!**



ATTENTION:

**SPECIAL ATTENTION AT THE TIME OF RELEASE THE LAST ANCHOR
BEFORE GROUND LEVEL. MAKE SURE THE CORRECT POSITION OF
THE STABILIZERS AND SUPPORT JACKS.
CASE OF SINGLE MAST, REMOVE SEVERAL PLATFORM MODULES
BEFORE STARTING MAST AND ANCHORAGE DISASSEMBLY.**



Step 2. Dismantling electrical equipment and cable system.

Once the lower limit is reached, disconnect power source and subsequently release the connector of the control panel groups and. Collect and store the cable into the holder.

Step 3. Dismantling the platform.

Disassemble the modules of platform, extensions and handrails in reverse mode to the previously described process.

Step 4. Dismantling base groups

Support the wheels of the machine on the ground acting on jacks of stabilizers, and let it rest. When the base group is free to move, you can move on the ground. Remove the base groups.



ATTENTION:

IMPORTANT NOTE ON COMPLIANCE WITH EUROPEAN DIRECTIVE 2006/42/CE.

CE DECLARATION OF CONFORMITY is valid only for machines purchased and installed with all original components supplied by CANOPY BRANDS EUROPE, S.L.U., and following all the instructions provided in this user's manual, ensuring compliance with all SSER Annex I of Directive 2006/42/EC.

Otherwise, the machine can't be put into service until the final assembly is declared in accordance with the specifications of Annex II of the Directive.

3. USING THE MACHINE



ATTENTION:

THE PLATFORM ONLY CAN BE OPERATED BY PERSONNEL APPOINTED, WHO HAVE BEEN TRAINED IN A SAFE OPERATION OF THE MACHINE AND THE MEASURES TO PREVENT HAZARDS.

3.1. Introduction.



WARNING:

EVERY DAY, BEFORE STARTING THE PLATFORM, RESPONSIBLE PERSON ON SITE SHOULD CHECK PROPERLY OPERATION OF MACHINE BASED ON AP. 4.1 DAILY MAINENANCE AND 3.5 CHECKING PLATFORM OPERATION BEFORE COMMISIONING, ON THIS USER'S MANUAL




WARNING:

BE SURE THAT ALL THE PERSONAL PROTECTIVE EQUIPMENT REQUIRED ON THE PLATFORM IS AVAILABLE BEFORE STARTING OPERATION.



PAY SPECIAL ATTENTION TO THE INTENDED HAZARDS ON THE PLATFORM.

3.2. Use of control panel



DESCRIPTION OF COMPONENTS OF CONTROL BOARD

1	GREEN PUSHBUTTON RUN – REARM	
2	RED PUSHBUTTON STOP – OUT OF SERVICE + RED LIGHT “OUT OF SERVICE”: Safety device	
3	YELLOW LIGHT	PEC-90 400V-3F: “PHASE ERROR”: Unbalanced, unordered, or lack of phase.
		PEC-90M 230V-1F: “MACHINE MOVING”
4	PUSHBUTTON ↑	
5	PUSHBUTTON ↓	
6	MANUAL LEVELING OF THE PLATFORM – ANLY FOR ASSEMBLY AND SERVICE OPERATION	
7	6: STOP RIGHT GROUP 7: STOP LEFT GROUP	
8	EMERGENCY STOP MUSHROOM	
9	MOTOR GROUP CONNECTOR – TWIN MAST 9: RIGHT GROUP CONNECTOR	
10	10: LEFT GROUP CONNECTOR BRIDGE CONNECTOR – SINGLE MAST	
11	ELECTRICAL SUPPLY CONNECTOR for electrical hose, with fast phase-change mechanism	
12	AUX. ELECTRICAL PLUG 220 V – 16 A.	
13	HORN	
14	BLUE LIGHT “ MOTOR THERMAL FAULT” + PUSHBUTTON REARM OF THERMAL RELAY	
15	MAIN OFF- ON SWITCH	



ATTENTION:
USE MANUAL LEVELING BUTTONS ONLY IF NECESSARY, BEFORE ADJUSTING POSITION OF AUTOMATIC LEVELING CAMS.
ONCE AUTOMATIC LEVELING CAMS ARE ADJUSTED, PLATFORM WILL CORRECT LEVELING ON NORMAL USE WITH NO OPERATOR INTERVENTION.



ATTENTION:
CASE OF TWIN MAST, CONNECT BOTH RIGHT AND LEFT MOTOR GROUPS TO THE INFERIOR CONNECTORS ON MAIN SWITHBOARD.
CASE OF SINGLE MAST, CONNECT MOTOR GROUP IN ONE OF THE SWITCHBOARD CONNECTORS. TO COMPLETE CONNECTION, BRIDGE CONECTOR 098.65 MUST BE CONNECTED.

3.3. Emergency stop



ATTENTION:
THERE'S AN EMERGENCY STOP MUSHROOM ON CONTROL BOARD THAT, IF PUSHED, IT STOPS PLATFORM IMMEDIATELY.



CASE OF PUSHING EMERGENCY STOP, PLATFORM CONTROL CAN'T BE REARMED UNTIL THE MUSHROOM IS RETURNED TO ITS ORIGINAL POSITION.



IMPORTANT:
CASE OF MISFUNCTIONING OR BREAKDOWN THAT REQUIRES EMERGENCY STOP ACTIVATION, ESPECIALLY IF PERSONAL SAFETY IS AFFECTED, PLATFORM SHOULDN'T BE REARMED UNTIL PLATFORM ON SITE RESPONSIBLE IS WARNED. HE WILL ASSESS THE HAZARD AND SOLVE THE PROBLEM.
DON'T KEEP WORKING ON THE PLATFORM WITHOUT DETECTING AND SOLVING THE PROBLEM.



3.4. Emergency lowering

Case of failure of electrical supply without restore, manual emergency lowering can be performed by acting on the motor brake manual release levers VERY CAREFULLY. This task should be carried out at short intervals to avoid overheating of centrifugal brakes. The emergency brakes act to limit lowering speed to a maximum of 20% overrated speed.



WARNING:
EMERGENCY LOWERING OPERATION IS A HAZARDOUS OPERATOIN, SO REMEMBER THAT:



- IT MUST BE PERFORMED BY TRAINED PERSONNEL
- IT SHOULD BE CARRIED OUT ONLY IF STRICTLY NECESSARY
- PLATFORM FLOOR LEVELING MUST BE PRESERVED




BRAKE RELEASE KEY

EMERGENCY LOWERING


EMERGENCY LOWERING PROCEDURE:

- SINGLE MAST PLATFORM  :
 PERFORM OPERATION VERY CAREFULLY, WITH PERIODICAL BREAKS EACH 6 m, TO AVOID OVERHEATING OF THE CENTRIFUGAL BRAKES. STOP LOWERING JUST BEFORE TOUCHING THE BASE BUFFERS.
- TWIN MAST PLATFORM  :
 PERFORM OPERATION VERY CAREFULLY, WITH PERIODICAL BREAKS EACH 6 m., TO AVOID OVERHEATING OF THE CENTRIFUGAL BRAKES.

PERFORM IN A COODINATE WAY ON LEFT AND RIGTH GROUP, SO THE INCLINATION OF THE PLATFORM NOT EXCEED 5°. STOP LOWERING JUST BEFORE TOUCHING THE BASE BUFFERS.



PLATFORM UNLEVELING DURING THE EMERGENCY LOWERING



IMPORTANT:

IF EMERGENCY LOWERING DOESN'T WORK, OR IF IT'S NOT POSSIBLE TO DESCEND THE PLATFORM, PLEASE STAND ON THE PLATFORM AND REQUEST FOR EXTERNAL ASSISTANCE. LEAVE THE PLATFORM COULD CAUSE SERIOUS HAZARD.

3.5. Checking platform operation before commissioning



IMPORTANT:

BEFORE PLATFORM COMMISSIONING, SERVICE RESPONSIBLE WILL CHECK BY MEANS OF VISUAL INSPECTION AND PERFORMING SHORT MOVEMENTS UP AND DOWN, IF IT IS IN COMPLIANCE WITH FOLLOWING POINTS:

- The platform is installed with all operational safety devices:
 - Motor brakes support load properly
 - Superior end track switch stops platform before reaching red mast.
 - Inferior end track switch stops platform before touching base buffers.
 - Door switch works properly (automatic closing works properly)
 - Mast detector (inductive sensor) works properly.
 - Light pilots and indicators on the control panel work properly.
 - Control pushbuttons are in good condition and work properly.
- There's no interference of hoist and external items, mast, ties, supporting structure, ...
- Automatic levelling system is adjusted, avoiding platform unleveling over 2°
- There's no accumulation of snow, ice, or materials over the platform or proximity.
- There's no overload and load diagrams are installed and visible on the platform.
- Base supporting jacks are installed properly, levelled and touching the ground.
- There's no outgoing elements on the facade that may interfere with platform travelling.

- Mast anchorages are installed and properly fitted to the facade structure.
- There are no power lines near the platform that endanger people or machines.
- There's a fenced area directly under the platform with barriers and indications to stop by passers accessing and standing there.
- Personnel on the platform have the necessary protective equipment.
- Access points and platform travel paths are sufficiently illuminated.
- All the platform bolts and safety pins are correctly installed.
- Guide rollers are not worn and there's not excessive gap with mast vertical tubes.
- Platform floor and auxiliary extension floor are firm and solid.
- Motor, pinion and pinion screws are tight, and pinion and rack engagement are correct.


IMPORTANT:

KEEP CLEAN AND ARRANGED THE WORK PLATFORM ZONE, ACCESS POINTS AND SURROUNDING AREAS.

3.6. Setting on OUT OF SERVICE.

IMPORTANT:

AT THE END OF DAILY WORK WITH THE PLATFORM, DESCEND TO LOWER POINT AND DISCONNECT ELECTRICAL SUPPLY.

FINALLY, DISCONNECT ELECTRICAL CABLE ON BUILDING SITE MAIN POWER SUPPLY. ALSO, WHEN INTENDING PROLONGED PERIODS OF NON-USE.

3.7. Environmental conditions for safe use of machine.

Temperature range for use:	-15°C – 45°C
Relative humidity:	30 % – 90 %
Max. height for installation:	1000 m (**)
Max. wind speed (SERVICE):	55 Km/h
Max. wind speed (ERECTION):	45 Km/h
Max. wind speed (OUT OF SERVICE *):	130 Km/h

(*) Position OUT OF SERVICE corresponds with hoist at the lowest point and power supply disconnected.

(**) For installation in locations above 1000 m of height., and if the temperature exceeds 45° C, ask to manufacturer for limitations.

ESTIMATIVE WIND SPEED. SCALE BEAUFORT			
	EFFECTS	EFFECTS	VELOCIDAD
0	Calm	Smoke rises vertically	0 -0,8 Km/h.
1	Light air	Smoke drift indicates wind direction	1 -5 Km/h.
2	Light breeze	Wind felt on face; leaves rustle	6 -11 Km/h.
3	Gentle breeze	Leaves, small twigs in constant motion	12 -19 Km/h.
4	Moderate breeze	Leaves and loose paper raised up	20 -28 Km/h.
5	Cool breeze	Small trees begin to sway	29 -38 Km/h.
6	Strong breeze	Large branches of trees in motion	39 -49 Km/h.
7	Moderate gale	Whole trees in motion	50 -61 Km/h.
8	Gale	Twigs and small branches broken off	62 -74 Km/h.
9	Strong gale	Slight structural damage occurs	75 -88 Km/h.
10	Whole gale	Seldom experienced on land	89-102 /h.

**ATTENTION:**

IF THERE'S NO ANEMOMETER, USE BEAUFORT SCALE TO EVALUATE ESTIMATED WIND SPEED. CASE OF EXCEEDING MAXIMUM ADMISSIBLE SPEED, STOP WORKING IMMEDIATELY AND DESCEND THE PLATFORM AND PUT IN OUT OF SERVICE MODE.

3.8. Intended applications.

- HOUSE BUILDING
- BUILDING FACADES
- REPAIR AND MAINTENANCE OF FACADES
- COVERING FACADES WITH MARBLE, FINISHING BRICKS, ...
- PAINTING FACADES
- INSTALLATION OF THERMAL AND ACOUSTIC INSULATION IN BUILDINGS
-

3.9. Applications and uses forbidden.


- DON'T use the platform in an explosive atmosphere.
- DON'T use the platform with more load than indicated in diagram for each platform configuration.
- DON'T transport material piled up at the ends of the platform floor, **all loads must be evenly distributed over the surface of the platform.**
- DON'T transport loads overhanging the platform.
- DON'T incline the platform over 2° on horizontal plane.
- DON'T use the platform in adverse weather conditions (See section 3.7)
- DON'T use the platform in unacceptable physical condition, treatment of serious illness, under alcoholic drinks effects, or under stress or mental overload condition.
- DON'T use the machine with other parts than those originals from the manufacturer.
- DON'T work without the necessary personal protection gear. These safety devices will vary upon different condition, therefore, a qualified person in the requirement of safety and health must evaluate the working conditions and mode of use before starting works.
- DON'T seat or climb over the handrails. The feet of users must always be on the platform floor.
- DON'T access the elevator with inadequate clothing, chains, pendants, rings or loose long hair
- DON'T place any scaffolding or ladder on top of the platform.
- DON'T leave the control panel key to any person other than the one in charge of maintenance or duly authorized.
- DON'T dismantle integrated equipment whose maintenance is only allowed authorized personnel (ex.: electrical motor, brake, gear-reductor).
- DON'T manipulate electrical system without express permission of the manufacturer.
- DON'T use the hoist without a differential switch on the main power supply connection line.
- DON'T use the machine in low light conditions. If necessary, local lighting will be installed in the elevator access points, illuminating the entire platform path.
- DON'T use ceilings or other protective against inclement weather over the platform, which may cause wall effect and can pose a significant increase of forces on the platform and its anchors, not included in the design calculation.

3.10. Annex for PEC-90M single-phase with 230V supply.



IMPORTANT:

PLATFORM PEC-90M SINGLE PHASE WORKS WITH 230V VOLTAGE, AND WITH SPECIAL ELECTRICAL EQUIPMENT AND MOTORS FOR 220 V 1-ph SUPPLY. REST OF COMPONENTS ARE COMPATIBLE WITH PEC-90 STANDARD PLATFORM.



CONTROL PANEL COMPONENTS DESCRIPTION

1	ELECTRICAL INSTALLATION DATA FOR SINGLE-PHASE VERSION
2	AUXILIARY POWER SOCKET 230 V – 16 A
3	POWER SOCKET – ELECTRICAL CABLE CONNECTION 220-250V
4	CABLE GLAND FOR CONNECTION TO RESISTORS
5	ACOUSTIC MOVEMENT WARNING

ELECTRICAL DATA:

ELECTRICAL DATA 1-ph PEC-90M	
CONNECTION:	200 – 240V _ 50/60Hz
NOMINAL CURRENT (230V):	
• SINGLE MAST:	10 A.
• TWIN MAST:	20 A.
CROSSSECTION WIRE	
• SINGLE MAST:	3 X 4 mm ²
• TWIN MAST:	3 X 6 mm ²
MAGNETOTHERMAL PROTECTION	25 A.
DIFFERENTIAL PROTECTION	25 A.
• SENSIBILITY:	300 mA.

4. MAINTENANCE OF THE MACHINE.

**WARNING:**

BEFORE PERFORMING ANY MAINTENANCE ACTION, TURN THE POWER OFF AND BLOCK VERTICAL MOVEMENT AT LEAST 1.8 m HEIGHT UNDER THE PLATFORM. MAINTENANCE TASKS MUST BE PERFORMED WITHOUT LOADS.

4.1. DAILY Maintenance.

The daily maintenance of the machine includes basic visual inspection operations by the person RESPONSIBLE for the machine on site. EVERY DAY, and always before use, a visual inspection of the platform must be carried out in accordance with the following points of attention:

- There's no accumulation of ice, snow or debris inside the platform, or in the proximity.
- Stabilizers and support jacks are in good condition and resting on the ground properly.
- There's no mast rack or vertical pipes undue wear.
- All handrails are installed according to user's manual and there's no dangerous gaps.
- The load diagram is installed and visible on the front of the platform.
- The area below the platform is bounded, preventing people from staying below.
- There are no bent or cracked parts (In this case they must be replaced by new ones).
- The wiring and connecting hose are in good condition and properly guided.
- Machine guide rollers are in contact with the faces of mast tubes, and without excessive gap.
- No overhead lines are present in the proximity, which may pose any hazard for user or machine.
- There are no objects that could come off the building in contact with the platform.
- The load placed on the machine does not exceed the external bodywork of the platform.
- Electric safety devices work properly (Doors, end track microswitches, mast detector...).
- Emergency stop works properly.
- Wall anchors are correct, and tie arms properly fixed to the mast.
- Rack / pinion engagement is correct.
- The control panel and switchboard are clean and dry.
- Every control and lights operate properly.
- The cable holder is on its correct position and wire is wound inside properly.

Once successfully checked all previous control points with a simple visual inspection and making small movements up and down with the platform, it can be used safely.

4.2. PERIODIC Maintenance.







WARNING:

IN CASE OF ELECTRICAL MALFUNCION IN THE HOIST, DO NOT HANDLE ELECTRICAL EQUIPMENT. MAINTENANCE AND INSPECTION OF THE HOIST ONLY MUST BE PERFORMED BY AUTHORIZED PERSONNEL.




Maintenance of the lift must be performed by the staff responsible for the machine and the results must be recorded in the MAINTENANCE RECORD.


MAINTENANCE TASKS SCHEDULE

OPERATION	ELEMENT	TOOL	PERIODICITY
1 	<ul style="list-style-type: none"> • PLATFORM UNION BOLTS AND SAFETY PINS. • PLATFORM FLOOR • ENDTRACK CAMS (SUPERIOR AND INFERIOR). • MAST SENSOR (CHECK GAP: ± 5 mm.). • MOTORGear OIL LEVEL. • DOOR MICROSWITCH • MOTORGear BOLTS AND NUTS (INSPECTION) • CONTROLBOARD LIGHTS AND BUTTONS. • MAST TUBES (WEAR, EROSION, WELDING) • MAST RACK (WEAR, EROSION, WELDING) • BRAKE RECTIFIER (INSPECTION) • ELECTRICAL WIRE (INSPECTION). • GUIDE ROLLERS (INSPECTION). • ANCHORAGE ARMS AND CLAMPS (INTERF / LOOSENING) • BASE BUFFERS (INSPECTION) 	-	40 h. WORK (MONTHLY)
2 	<ul style="list-style-type: none"> • ELECTRIC TEST FOR MOTOR (Pag.53) 	AMPERIMETER	40 h. WORK (MONTHLY)
3 	<ul style="list-style-type: none"> • MAST RACK • GEAR MOTOR PINION 	LITIUM GREASE	40 h. WORK (MONTHLY)
4 	<ul style="list-style-type: none"> • MAST SCREWS • GUIDE ROLLERS SCREWS. • ANCHORAGE TO STRUCTURE SCREWS • HANDRAILS SCREWS 	WRENCH	QUARTERLY (4/YEAR)
5	<ul style="list-style-type: none"> • CENTRIFUGAL TEST TESTING 	UNLOCK LEVER	QUARTERLY (4/YEAR)
6 	<ul style="list-style-type: none"> • GUIDE ROLLER DIMENSION. • RACK DIMENSIONS • GEARMOTOR PINION STRING • MOTORBRAKE 	CALIBER CALIBER MICROMETER GAUGES	SEMESTERLY (2 TIMES/YEAR)
7 GENERAL REV. (AFTER DISMANTLING OR PROLONGED NON-USE PERIOD)	<ol style="list-style-type: none"> 1. DEFORMATION OR DAMAGE ON MASTS, ANCHOR, DOORS, HANDRAILS, FLOOR, ... 2. GEARMOTOR INSPECTION (SEE MAINT. INSTRUCTIONS: MOTORBRAKE AND GEARMOTOR) 		


MECHANICAL CHECKING DIAGRAM



CONTROL MEASURES K [mm]		
	Nom.	Min.
PINION Z16	38	35




OVERLAP □ [mm]		
	Nom.	Min.
□	10	8,3




CONTROL MEASURES □ [mm]		
	Nom.	Min.
□ A	4,1	3
□ B	29,1	28

CHECKING RACK AND PINION WEAR





CHECKING MAST GUIDE ROLLERS



ROLLERS SUBSTITUTION





IMPORTANT:
 DUE TO THE POSITION OF THE LOAD SIDE ROLLERS MAY NOT CONTACT THE MAST CONTINUOUSLY ON BOTH SIDES.
 THIS DOES NOT INDICATE A MALFUNCTIONING OF THE HOIST.



CHECKING MAST WEAR AND DAMAGE



ATTENTION:
 CHECK FOR POSSIBLE DAMAGE AND EXCESSIVE WEAR OF THE MAST TUBES BEFORE ASSEMBLY AND LATER, WITH THE PERIODICITY INDICATED.



Properties			Method	Shell Omala S4 GXV 220
Kinematic Viscosity	@40°C	mm ² /s	ASTM D445	220
Kinematic Viscosity	@100°C	mm ² /s	ASTM D445	30
Viscosity Index			ASTM D2270	171
Flash Point (COC)		°C minimum	ASTM D92	240
Pour Point		°C	ASTM D97	-42
Density	@15°C	kg/m ³	ASTM D4052	864
Four Ball EP Weld load		kg minimum	ASTM D2783	250
FZG Load Carrying Test		failure load stage minimum	A/8,3/90	14

GEARBOX MAINTENANCE



IMPORTANT:
GEARBOXES ARE INSTALLED COMPLETE WITH SYNTHETIC 220 OIL FOR "LIFE LUBRICATION", IN THE ABSENCE OF EXTERNAL CONTAMINATION.
IF IT IS NECESSARY TO REPLACE THE OIL, REPLACE IT WITH OIL WITH THE VISCOSITY GRADE INDICATED IN THE TABLE.




IMPORTANT:
GEARBOX LUBRICATION OIL IS PREPARED TO USE WITH AMBIENT TEMPERATURE RANGE $0^{\circ}\text{C} < T < 40^{\circ}\text{C}$, WITH PEAKS TILL $-20^{\circ}\text{C} < T < 50^{\circ}\text{C}$.
REPLACE THE OIL COMPLETELY. DO NOT MIX DIFFERENT OILS.


AUTOMATIC GREASING SYSTEM (OPT)




AUTOMATIC GREASING CENTER



PINION GREASING POINTS POSITION



GREASING FLOW DISTRIBUTOR



GREASING SYSTEM TECHNICAL FEATURES


Grease TYPE	Lithium grease	
Types of grease allowed:	NLGI	ASTM
Very soft	0	355 – 385
Medium soft	1	310 – 340
Medium (Recommended)	2	265 - 295
Tank capacity:	0,5 l.	
Lubrication speed:	2x12 gr/h.	
Tank life:	~ 70 h. (Hoist working)	






- CONTROL LOCKED (PRESS ↑↓ TO UNLOCK)**
- YELLOW – GREASING PUMP WORKING**
- RED – GREASING MOTOR BLOCKED**
- RED – MIN. GREASE TANK LEVEL**
- RED – VOLTAGE UNDER MIN. LEVEL**
- CANCEL ALARM / GREASING EXTRA CYCLE**
- INCREASE OR REDUCE GREASING FREQ. /CYCLE.**
- SIMULTANEUN PRESS. – LOCK CONTROL**

GREASING UNIT CONTROL CONSOLE

CAJA CONEXION MOTOR:
/MOTOR TERMINAL BOX:
/CONNEXION MOTEUR:
220 ↔ 260 V 50/60Hz + PE



ELECTRIC CONNECTION OF GREASIG SYSTEM

ELECTRIC BRAKE-MOTOR MAINTENANCE INSTRUCTIONS

ELECTRIC MOTOR WITH D.C. BRAKE AND MANUAL RELEASE LEVER

CONTROL DIMENSIONS [mm]

	Nom.	Max.	Min.
Entferr (air gap)	-	0,45	0,3
Brake disc thickness (e)	-	-	7
Lever gap (g)	0,6	-	-

CHECKING BRAKE WEAR


IMPORTANT:
DO NOT MANIUPULATE GREASING CYCLES. CHECK PERIODICALLY AVAILABLE GREASE LEVEL. CASE OF MALFUNCTIONING OF THE PUMP, PLEASE CONSULT THE MANUFACTURER.



IMPORTANT:
EXCESSIVE AIR-GAP, SUPERIOR TO MAX. VALUE, COULD PRODUCE BRAKE TORQUE DECREASING. CHECK PERIODICALLY AIR-GAP AND ALSO BRAKE DISK THICKNESS, ACCORDING TO TABLE ABOVE.

BRAKE ADJUSTMENT PROCEDURE:

1. Release nuts **Nº32**, located 3 positions separated 120°
2. Screw fastening screws **Nº25**. [Case of flywheel, act through the proper holes], in order to reach minimum airgap, measuring by a thickness gauge in 3 positions at 120° near the guiding bushes **Nº28**.
3. Tighten nuts **Nº32** keeping in position fastening screws **Nº25**.
4. Verify the obtained air-gap value and compare with values in table above.



IMPORTANT:
AFTER SEVERAL AIR-GAP ADJUSTMENTS, VERIFY THAT BRAKE DISK THICKNESS (e) IS NOT LOWER THAN MINIMUM VALUE STATED IN TABLE. IF NECESSARY, REPLACE THE BRAKE DISK.





IMPORTANT:
AFTER BRAKE ADJUSTMENT, CHECK RELEASE IF LEVER BAKCLASH (g) ALLOWS MANUAL BRAKE RELEASING PROPERLY. IF NECESSARY, AMEND (g) VALUE ACCORDING TO TABLE ABOVE.



D.C. BRAKE POWER SUPPLY RECTIFIER

BRAKE RECTIFIER CHECKING TABLE

a) Input voltage Vac	(~ . ~)	230 Vac
b) Output voltage Vdc	(- . +)	75 – 105 Vdc
c) Coil resistance value (*)	(- . +)	±250 Ω



a) ~.~ ; b) - . +

c) Ω

BRAKE RECTIFIER COMPROBATION TABLE




IMPORTANT:
CHECK INPUT VOLTAGE Vac AND OUTPUT VOLTAGE Vdc WITH HOIST WORKING, IN ORDER TO VERIFY RECTIFIER PERFORMANCE.
¡¡ ATENTION: ELECTRICAL CONTACT HAZARD!!




IMPORTANT (*):
IN ORDER TO CHECK BRAKE COIL, RELEASE RECTIFIER VOLTAGE OUTPUT WIRES (+, -) AND VERIFY COIL RESISTANCE VALUES IN TABLE ABOVE, ACCORDING TO POINT c) INSTRUCTION. REPLACE BRAKE COIL IF NECESSARY.

CONSUMPTION TEST FOR ELECTRIC MOTOR




IMPORTANT:
THE TEST MUST BE PERFORMED BY AN AUTHORIZED TECHNICAL PERSON, SPECIALLY TRAINED TO HANDLE ELECTRICAL EQUIPMENT.


ATTENTION:
⚡ ELECTRIC SHOCK HAZARD!!



1. Locate maximum load on the platform, according to instructions in user's manual.
2. Check and adjust values for thermal relays RT1,...,RT4: **1,9A**.
3. Release motor terminal box cover.



4. Check amperage in all phases F1, F2, F3 [Amp.] on both motors long enough to stabilize electrical current consumption values. For each drive unit, must be met:




TEST OK CONDITION		
	Max.	Difference M1 – M2
Current consumption M1	1,9 A	< 0,5 A
Current consumption M2		

TEST OK CONDITION (PEC-90M)		
	Max.	Difference M1 – M2
Current consumption M1	3,8 A	< 0,9 A
Current consumption M2		

5. Remove the load of the platform and reassembly motor terminal box cover.



IMPORTANT:
IN THE CASE OF CONDITIONS OF THE TABLE ABOVE ARE NOT MET, THE PLATFORM MUST BE STOPPED THE PLATFORM AND THE GEARMOTORS MUST BE CHECKED. CASE OF DOUBTH, CONSULT THE MANUFACTURER.




IMPORTANT:
CASE OF RT1,...,RT4 TRIP, M1 - M2 MOTOR CURRENT CONSUMPTION AND MOTOR ELECTROMAGNETIC BRAKE MUST BE CHECKED.

MOTOR BRAKE AND GEARMOTOR VERIFICATION TEST



IMPORTANT:



AFTER EACH DISASSEMBLY OR NON-USE PERIOD AND BEFORE THE MACHINE SERVICE START, VERIFY THE GEARMOTOR, CENTRIFUGAL BRAKE AND MOTOR BRAKE



1. The base will settle over the buffers, and it will have an additional mast allowing some movement.
2. Run a test without load and then run it with the appropriate test load (PEC 90: **1000Kg**)
3. Make small up and down movements verifying non-slip stops.
4. Manually free the brake lever alternatively, verifying a single brake can hold the platform without slipping.
5. **Check noises and vibrations absence while platform is moving.**

Rossi		a subsidiary of the Kalsetti group www.rossi-group.com		IEC 60034-1 IE1 CE made in Italy	
MOT. 3- N	0620211 01/11	IP 55	AMB. 40°C IC 411	I.C.L. F S 1 CONT.	
HBZ 80B4	B5	kg 9.2			
Brake	Nm	V~/ Hz	A	#/#/#	V=
BZ04	15	110+480/50+60	0.11	RM1	103
Expansion					
Δ V	Y	Hz	A	kW	min ⁻¹ cos φ
230 / 400		50	3.3 / 1.9	0.75	1400 0.72
265 / 460		60	3.3 / 1.9	0.75 SF1.15	1690 0.68
50Hz IE1 74.7(100%) 74.2(75%) 70.5(50%)					
60Hz NEMA NOM.EFF. 78,5% 1HP DES.C. CODE K					

**MOTOR PLATE EXAMPLE TO SPARE PART REQUESTING
GEARMOTOR – ELECTRIC MOTOR SUBSTITUTION**



1. Clean motor and gearbox surface to be fitting, thoroughly.
2. Install the pinion spacer in the motor axle with locking adhesive.
3. Fit motor flange and gearbox with fixing screws and washers.

PREVENTIVE MAINTENANCE OF MOTOR AND ELECTRIC BRAKE:

- Keep external surfaces free from oil, dust and machining residuals.
- Keep free all air cooling circuits (housing, air input).
- Check that electric connections are fitted properly.
- Check the correct tightness of the motor and that there are no leaks in the seals.
- Check that motor run is free from vibrations and anomalous noises.

**IMPORTANT:**

TO ORDER SPARE PARTS FOR THE MOTOR OR ELECTRIC BRAKE, IT IS NECESSARY TO REFER TO THE MOTOR PLATE INFORMATION. THAT WAY, SPARE PART SUPPLY ERRORS ARE AVOIDED.

**INFORMATION:**

IF YOU REQUIRE TECHNICAL ASSISTANCE FOR GEARMOTOR, YOU CAN CONTACT THE MANUFACTURER, OR THE SERVICE MOTOR MANUFACTURER IN EACH COUNTRY. SEE CONTACT POINTS: <http://www.rossi-group.com>


ATTENTION:

AFTER EACH NEW PLATFORM ASSEMBLY, AND THEN EVERY 4 MONTHS, OPERATION OF CENTRIFUGAL BRAKE MUST BE CHECKED.

CENTRIFUGAL BRAKE TESTING
Test condition:



- Single mast or twin mast configuration.
- At least one/two persons on the platform (single mast / twin mast)
- Rated load on the platform.
- Unlock lever for emergency lowering are available over the platform.
- If already used before, wait for at least 30' from the last centrifugal brake activation.
- The area below the platform is bounded, preventing people staying below

Test procedure:

- Raise the platform 10 m. from the ground.
- Be sure that there's no elements on the travel path that could hit the platform.
- SINGLE MAST: Unlock motor brakes with the lever until the platform drops.
- TWIN MAST: Unlock motor brakes SIMULTANEOUSLY, paying special attention to the platform levelling, that shouldn't exceed 5° of mislevelment.

Verifications:

- During the test, check that after reaching the speed centrifugal brake performance (+20% of rated speed), the machine goes down without overspeed → **1 meter ~ APROX. 6 sec.**
- Stop the test when the platform is about 1 m above the ground. Finish the movement by using the normal controls of the platform.
- Case of brake malfunction and if excessive speed is reached, STOP THE TEST IMMEDIATELY and descend the platform with normal controls to the lowest point.
- If the test is satisfactory, the platform can be operated again. **LOG RESULT ON MAINTENANCE RECORD**
- If the test is not successful, proceed to check LINING (4), SPRINGS (6), and BEARINGS (9).


FRENO CENTRIFUGO

 $\varnothing_f = 92 \text{ mm.}$

$\varnothing_f < 88 \text{ mm} \rightarrow$ REPLACE MASA AND MUELLES

Nº	Element	Qty.
01	CLUTCH DRUM	1
02	CORE	1
03	BOLT	4
04	LINING	4
05	WHASER	4
06	SPRING	2
08	KEY	1
09	BEARING	1

4.3. Instructions for troubleshooting.

GEARMOTOR		
Problem	Probable cause	Solution
Motor doesn't work	Supply line fault. Motor box connection fault Brake doesn't work. Motor internal fault	Check 3-phase electric supply. Check motor connection. Check brake s/section. 4.2 Consult the manufacturer
Motor can't raise rated load	Motor connection problem Insufficient voltage supply Supply voltage drop	Check motor connection. Check supply line. Check supply cross section wire
Motor overheats	Motor connection error Motor locked. Voltage supply error Fan covers obstructed. Insufficient ventilation air flow Brake doesn't work	Check motor connection. Check brake s/section. 4.2 Check supply line. Release air passage to the fan. Check for obstacles to ventilation. Check brake s/section. 4.2
Excessive current consumption	Brake locked. Motor coil damage Gearbox fault	Check brake s/section. 4.2 Ask to the manufacturer. Check motor s/page 53
Motor brake doesn't release	Brake connection fault. Rectifier damaged Excessive brake airgap Brake coil damaged	Check motor connections. Check rectifier s/section. 4.2 Check air-gap s/section. 4.2 Check brake coil s/section. 4.2
Brake doesn't hold the load	Excessive brake airgap Brake coil damaged. Excessive brake disk wear	Check brake coil s/section. 4.2 Consult the manufacturer. Replace brake disk
Excessive brake noise	Excessive airgap	Check brake s/section. 4.2
Gearmotor sounds abnormally	Lack of oil on the gearbox. Gearbox bearing failure	Check oil level and oil leaks. Consult the manufacturer

GENERAL		
Problem	Probable cause	Solution
Control board doesn't work. (NONE OF PILOT LIGHTS ARE ON)	Emergency stop activated. Lack of electrical supply Connection error	Check emergency stop. Check electrical supply. Check single drive unit connector
Yellow light PHASE ERROR is active	Phase error /unbalanced phase	Change supply phase connection
Platform control panel doesn't rearm. (OUT OF SERVICE RED LIGHT ON)	Safety device activated	Check safety devices: - Upper limit microswitch (FCSS) - Lower limit microswitch (FCSB) - Mast detector (IND) - Anchorage safety system (FCSA+FCSE) - Levelling safety microswitch (FCNIVS) - Door safety microswitch (FCP)
Platform doesn't move (NONE OF PILOT LIGHTS ARE ON)	Motor thermal protection activated. Excessive adjustment of levelling system	Check thermal relays RT1...,RT4. Check levelling microswitch (FCNIV)
Platform moves doing abnormal noise and doesn't do it softly	Guide rollers or bears are damaged. Lack of grease on pinion. Lack of grease on rack	Check guide rollers and bears. Grease rack-pinion engagement
Platform slides down when loads on it	Brake damage or failure. Overload	Check brake s/section 4.2. Remove overload
Electrical motor starts difficulty	Brake motor doesn't work. Overload Insufficient voltage supply	Check brake s/section. 4.2 Check load and positioning on the platform. Check electrical supply voltage
Protection MT1 or MT2 failure	Problem in voltage transformer or control circuit.	MT1: Replace control transformer. MT2: Check electrical control circuit
Platform stops suddenly	Electrical supply failure Safety switch failure or misadjustment	Check electrical connection. Check safety microswitches
Platform vibrates abnormally	Screws or rollers untightened. Rack-pinion engagement problem. Lack of lubrication Excessive wear in mast vertical tubes	Check guide rollers adjustment. Check rack-pinion gear. Lubricate rack and pinion. Check mast for tube wear

Platform moves with interruptions	Electrical wiring damaged Safety switch failure	Check wiring status. Check safety switches
The platform can't lift the load	Inadequate wire cross-section Motor brake failure Voltage supply failure on site Inadequate generator power supply (KVA)	Check communication cable. Check / replace motor brake. Check voltage supply. Check generator supply power (KVA)



**ATTENTION:
CHECK IF HOIST IS CONNECTED TO A POWER SUPPLY EQUIPED WITH DIFFERENTIAL PROTECTION 300mA.**

4.4. Maintenance record.

According to the procedure specified in the user's manual, the person responsible for maintenance of the hoist should fill this table according to the frequency indicated, for the record of scheduled tasks.

Nb	DATE	MAINTENANCE TASK	NAME	SIGNATURE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				

Nb	DATE	MAINTENANCE TASK	NAME	SIGNATURE
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				
71				
72				
73				
74				
75				
76				
77				
78				
79				
80				
81				
82				
83				
84				
85				

4.5. Breakdown record

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

		PARTS TO CHANGE			
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person

User

.....

.....

Place

Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

		PARTS TO CHANGE			
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person

User

.....

.....

Place

Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

		PARTS TO CHANGE			
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person

User

.....

Place Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

		PARTS TO CHANGE			
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person

User

.....

Place Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

		PARTS TO CHANGE			
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person

User

.....

Place Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....


		PARTS TO CHANGE			
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person


User

.....

Place Date.....


PEC 90 TWIN MAST WORK PLATFORM

Lateral Length	Modules	Maximum load (Kg)	Central Platform (m)	Modules	Maximum Load (Kg)	LOADING EXAMPLES	
						Total Length (m)	Maximum load (Kg)
0,82 m	1 X 0,82 m	500 Kg (1p. + 420 Kg)	3	2 x 1,5 m	1.100	6,26	2.100 (4p.+ 1780 Kg)
			3,82	2 x 1,5 m + 1 x 0,82 m	1.050	7,08	2.050 (4p.+ 1730 Kg)
			4,5	3 x 1,5 m	1.000	7,76	2.000 (4p.+ 1680 Kg)
			5,32	3 x 1,5 m + 1 x 0,82 m	950	8,58	1.950 (4p.+ 1630 Kg)
1,5 m	1 X 1,5 m	400 Kg (1p. + 320 Kg)	6	4 x 1,5 m	900	10,62	1.700 (4p.+ 1380 Kg)
			6,82	4 x 1,5 m + 1 x 0,82 m	850	11,44	1.650 (4p.+ 1330 Kg)
			7,5	5 x 1,5 m	800	12,12	1.600 (4p.+ 1280 Kg)
			8,32	5 x 1,5 m + 1 x 0,82 m	750	12,94	1.550 (4p.+ 1230 Kg)
2,32 m	1 X 1,5 m + 1 X 0,82 m	250 Kg (1p. + 170 Kg)	9	6 x 1,5 m	700	15,26	1.200 (4p.+ 880 Kg)
			9,82	6 x 1,5 m + 1 x 0,82 m	650	16,08	1.150 (4p.+ 830 Kg)
			10,5	7 x 1,5 m	625	16,76	1.125 (4p.+ 805 Kg)
			11,32	7 x 1,5 m + 1 x 0,82 m	600	17,58	1.100 (4p.+ 780 Kg)
3 m	2 X 1,5 m	200 Kg. (1p. + 120 Kg)	12	8 x 1,5 m	575	19,62	975 (4p.+ 655 Kg)
			12,82	8 x 1,5 m + 1 x 0,82 m	550	20,44	950 (4p.+ 630 Kg)
			13,5	9 x 1,5 m	500	21,12	900 (4p.+ 580 Kg)
			14,32	9 x 1,5 m + 1 x 0,82 m	450	21,94	850 (4p.+ 530 Kg)
			15	10 x 1,5 m	400	22,62	800 (4p.+ 480 Kg)



PEC 90 SINGLE MAST WORK PLATFORM

Lateral Length	Modules	Maximum load (Kg)	LOADING EXAMPLES	
			Total Length (m)	Total Length (m)
0,82 m	1 X 0,82 m	500 Kg (1p. + 420 Kg)	2,45	1.000 Kg (2p.+ 840 Kg)
1,5 m	1 X 1,5 m	400 Kg (1p. + 320 Kg)	3,81	800 Kg (2p.+ 640 Kg)
2,32 m	1 X 1,5 m + 1 X 0,82 m	250 Kg (1p. + 210 Kg)	5,45	500 Kg (2p.+ 340 Kg)
3 m	2 X 1,5 m	200 Kg (1p. + 120 Kg)	6,81	400 Kg (2p.+ 240 Kg)

- SET UPS IN THIS TABLE ARE MERELY INFORMATIVE AND MAY VARY DUE TO MACHINE MODULARITY.
- LOAD VALUES INCLUDE PERSONNEL, TOOLS AND MATERIALS WEIGHT.
- EXTENSIONS OF PLATFORM DECKS SHALL ONLY BE USED WHILE WORKING. PLACING LOADS ON THEM IS FORBIDDEN.
- LOADS MUST BE EVENLY DISTRIBUTED ALONG THE PLATFORM.
- ON SINGLE MAST SET UPS, LATERAL LENGTHS SHALL BE IDENTICAL.
- THE MAXIMUM ALLOWED FORCE FOR HAND TOOLS USED IN THE WORK PLATFORM IS 1500 N